


User Guide for Nokia Video Call Stand PT-8 (for Nokia 6630)



9235572

Issue 1

DECLARATION OF CONFORMITY

We, NOKIA CORPORATION, declare under our sole responsibility that the product

PT-8 is in conformity with the provisions of the following Council Directive: 1999/5/EC.

A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/.



Copyright © 2004 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia, Nokia Connecting People and Pop-Port are registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of particular products may vary by region. Please check with the Nokia dealer nearest to you.

9235572 / Issue 1

Contents

Contents.....	4
For your safety	5
Introduction.....	7
1. Overview	9
2. Using the stand	11
Placing your phone in the stand.....	11
Making a video call	14
Care and maintenance	15

For your safety

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.



QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.



WATER-RESISTANCE

Your device is not water-resistant. Keep it dry.

When using the features of this device, obey all laws and respect the privacy and legitimate rights of others.

■ Chargers and batteries

Check the model number of any charger before use with this device. This device is intended for use when supplied with power from AC-1 and ACP-12.



Warning! Use only chargers approved by Nokia for use with this particular enhancement. The use of any other types may invalidate any approval or warranty, and may be dangerous.

For availability of approved chargers, please check with your dealer.

When you disconnect the power cord of any enhancement, grasp and pull the plug, not the cord.

Introduction

The Nokia Video Call Stand PT-8 allows you to use your Nokia 6630 phone for hands-free video calls. Thanks to its foldable, compact size and light weight, the stand is easy to carry.

Read this user guide carefully before using the stand. More detailed information is provided in the user guide of your Nokia 6630 phone. Do not use this user guide in place of the user guide of your phone, which provides important safety and maintenance information. Note that the stand is designed for indoor use only.

You may use the stand in the following ways:


- View your image and the other caller's image from your phone display during a video call.
- Adjust the camera and viewing angle by tilting the stand to the desired position.

I n t r o d u c t i o n

- Use your Bluetooth headset, such as Nokia Wireless Headset HDW-3, with your phone when you want to call in privacy.
- Use the functions of your phone normally while the phone is connected to the stand. The stand uses the loudspeaker and microphone of your phone.
- Charge your phone while it is connected to the stand.

1. Overview

Nokia Video Call Stand has the following parts:



Camera lens (1)

The indicator light (2) is green when the stand is powered by the AC-1 or ACP-12 charger and the phone is plugged into the Pop-Port connector. When the light is continuously on, the phone and stand are ready for video calling.

Overview

Pop-Port connector (3)


Charger jack (4)

The dc cable (5) allows you to charge your phone while the phone is placed in the stand and the dc plug is connected to the phone.

2. Using the stand

■ Placing your phone in the stand

1. Detach the plug-end of the dc cable from the back of the stand.



Using the stand


2. Connect the stand to an AC-1 or ACP-12 charger.



3. Plug the charger into a wall socket. The green indicator light flashes briefly.

Keep the stand connected to the wall socket when in use.

4. Plug the phone into the stand, and insert the plug-end of the dc cable into the charger jack of your phone.



The charger also charges the phone battery.

5. Verify that the indicator light is green, indicating that the stand is ready for use.

■ Making a video call

1. When the phone is properly placed in the stand, adjust the camera and viewing angle by tilting the stand to the desired position.
2. Make or answer a video call as described in the user guide of your Nokia 6630 phone.

For video recording, use the camera of the stand. For audio, you can use the microphone and loudspeaker of the phone or a Bluetooth headset connected to the phone.

Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep all enhancements out of the reach of small children.
- Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.

Care and maintenance

- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use a soft, clean, dry cloth to clean any lenses (such as camera, proximity sensor, and light sensor lenses).

If the device is not working properly, take it to the nearest authorized service facility for service.