






User Guide for Nokia Video Call Stand PT-8 (for Nokia 6630)



9235589
Issue 1



DECLARATION OF CONFORMITY

We, NOKIA CORPORATION, declare under our sole responsibility that the product PT-8 is in conformity with the provisions of the following Council Directive: 1999/5/EC. A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/.



Copyright © 2004 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia, Nokia Connecting People and Pop-Port are registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of particular products may vary by region. Please check with the Nokia dealer nearest to you.

9235589 / Issue 1

Contents

Contents

For your safety.....	4
Introduction	5
1. Overview	6
2. Using the stand.....	7
Placing your phone in the stand	7
Making a video call.....	8
Care and maintenance.....	9

English

For your safety

For your safety

Read these simple guidelines. Not following them may be dangerous or illegal.
Read the complete user guide for further information.



QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.



WATER-RESISTANCE

Your device is not water-resistant. Keep it dry.

When using the features of this device, obey all laws and respect the privacy and legitimate rights of others.

Chargers and batteries

Check the model number of any charger before use with this device. This device is intended for use when supplied with power from AC-1 and ACP-12.



Warning! Use only chargers approved by Nokia for use with this particular enhancement. The use of any other types may invalidate any approval or warranty, and may be dangerous.

For availability of approved chargers, please check with your dealer.

When you disconnect the power cord of any enhancement, grasp and pull the plug, not the cord.

Introduction

English

The Nokia Video Call Stand PT-8 allows you to use your Nokia 6630 phone for hands-free video calls. Thanks to its foldable, compact size and light weight, the stand is easy to carry.

Read this user guide carefully before using the stand. More detailed information is provided in the user guide of your Nokia 6630 phone. Do not use this user guide in place of the user guide of your phone, which provides important safety and maintenance information. Note that the stand is designed for indoor use only.


You may use the stand in the following ways:

- View your image and the other caller's image from your phone display during a video call.
- Adjust the camera and viewing angle by tilting the stand to the desired position.
- Use your Bluetooth headset, such as Nokia Wireless Headset HDW-3, with your phone when you want to call in privacy.
- Use the functions of your phone normally while the phone is connected to the stand. The stand uses the loudspeaker and microphone of your phone.
- Charge your phone while it is connected to the stand.

Overview

1. Overview

Nokia Video Call Stand has the following parts:



Camera lens (1)

The indicator light (2) is green when the stand is powered by the AC-1 or ACP-12 charger and the phone is plugged into the Pop-Port connector. When the light is continuously on, the phone and stand are ready for video calling.

Pop-Port connector (3)


Charger jack (4)

The dc cable (5) allows you to charge your phone while the phone is placed in the stand and the dc plug is connected to the phone.

2. Using the stand

■ Placing your phone in the stand

1. Detach the plug-end of the dc cable from the back of the stand.



2. Connect the stand to an AC-1 or ACP-12 charger.




3. Plug the charger into a wall socket. The green indicator light flashes briefly.

Keep the stand connected to the wall socket when in use.

Using the stand

4. Plug the phone into the stand, and insert the plug-end of the dc cable into the charger jack of your phone.



The charger also charges the phone battery.

5. Verify that the indicator light is green, indicating that the stand is ready for use.

■ Making a video call

1. When the phone is properly placed in the stand, adjust the camera and viewing angle by tilting the stand to the desired position.
2. Make or answer a video call as described in the user guide of your Nokia 6630 phone.

For video recording, use the camera of the stand. For audio, you can use the microphone and loudspeaker of the phone or a Bluetooth headset connected to the phone.








Care and maintenance


English

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep all enhancements out of the reach of small children.
- Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use a soft, clean, dry cloth to clean any lenses (such as camera, proximity sensor, and light sensor lenses).

If the device is not working properly, take it to the nearest authorized service facility for service.









Nokia PT-8

視像通話座的使用指南

(適用於 Nokia 6630)



第 1 版



一致性聲明

本公司 (NOKIA CORPORATION) 聲明產品 PT-8 符合下列說明委員會 (Council Directive) 的規定：1999/5/EC。

一份一致性聲明的副本可於

http://www.nokia.com/phones/declaration_of_conformity/ 內找到。



Copyright © 2004 Nokia. 版權所有。

未取得 Nokia 的書面同意，嚴禁以任何形式複製、傳輸、分發或儲存本文件部分或全部內容。

Nokia、Nokia Connecting People 和 Pop-Port 是 Nokia Corporation 的註冊商標。本文件中所提及的其他產品與公司名稱可能分別為其各自擁有者之商標或註冊名稱。

Nokia 奉行持續研發的政策。Nokia 保留對本文件中所描述產品作出改變和改進的權利，恕不預先通知。

在任何情況下，對資料遺失、收益損失或因此所造成任何特別、意外、隨之而來或非直接的損壞，Nokia 恕不負責。

本文件的內容以「現有形式」提供。除所適用的法律外，有關本文件內容的正確性與可靠性，不論是明示或默示性，包括但不僅限於，對特殊目的的商用性與適用性都不提供任何保證。Nokia 保留隨時修訂或收回本文件之權利，恕不預先通知。

特定的產品的供應可能根據地區的不同而有所分別。請向您最近的 Nokia 經銷商查詢。

第 1 版

目錄

目錄

安全規定	4
簡介	5
1. 概覽	6
2. 使用通話座	7
將手機放於通話座	7
撥打視像電話	8
保養及維修	9

中文香港

安全規定

安全規定

請閱讀下列簡易的使用原則。不遵守這些規則可能會產生危險或觸犯法律。請閱讀完整的用戶指南以獲取進一步資料。



合格的服務
只容讓合資格的服務人員安裝或維修本產品。



與其他裝置相連
在連接任何其他裝置時，請先閱讀其使用指南，獲取詳細的安全指示。不要連接不兼容的產品。



防水性
您的裝置並不防水。請保持乾燥。

使用本裝置的功能時，請遵守所有法律並尊重他人的隱私和合法權利。

■ 充電器和電池

在使用充電器前請先檢查充電器的型號。此裝置適用的充電器為 AC-1 和 ACP-12。



警告！ 僅使用經 Nokia 許可的、供本特定配套使用的充電器。使用其他未經許可的配件，可能會令保養失效，甚至造成危險。

關於許可充電器的供應情況，請向您的經銷商查詢。

當您切斷任何配件的電源時，請握住插頭然後拔出，不要拉電線。

簡介

PT-8 Nokia 視像通話座能讓您使用 Nokia 6630 手機進行免提視像通話。通話座可摺疊、小巧、輕盈，易於攜帶。

在使用通話座前請仔細閱讀本用戶指南。您的 Nokia 6630 手機的用戶指南內提供更多詳細資料。請不要以本使用指南取代您的手機的用戶指南，用戶指南提供了重要的安全和保養資料。請注意通話座僅為室內使用而設。


您可以透過以下方式使用通話座：

- 在視像通話過程中，於您手機的螢幕上查看您的影像及其他通話者的影像。
- 將通話座傾斜至想要的位置以調較相機和檢視角度。
- 當您想進行私人通話時，把您的藍芽耳機 (例如：HDW-3 Nokia 無線耳機) 與您的手機一起使用。
- 當手機已連接至通話座時，您可以正常使用手機的功能。通話座使用您手機的喇叭和麥克風。
- 當手機連接至通話座時，請為手機充電。

概覽

1. 概覽

Nokia 視像通話座包括以下部分：



相機鏡頭 (1)

當使用 AC-1 或 ACP-12 為通話座充電且手機已插入 Pop-Port 插孔時，指示燈 (2) 為綠色。當指示燈一直開啓時，表示手機及通話座已為視像通話作好準備。

Pop-Port 插孔 (3)


充電器插座 (4)

當手機置於通話座上且直流電插頭連於手機時，直流電傳輸線 (5) 便可為手機充電。

2. 使用通話座

■ 將手機放於通話座

1. 從通話座的背部取下直流電傳輸線的末端。




2. 將通話座連接至 AC-1 或 ACP-12 充電器。



3. 將充電器插入牆上的插座。綠色指示燈便會簡短閃爍。
當使用通話座時，請將其連接至牆上的插座。

使用通話座

4. 將手機插入通話座，把直流電傳輸線的末端插入您手機的充電器插座。



充電器亦會為手機電池充電。

5. 注意當指示燈為綠色時，表示通話座已準備就緒，等待使用。

■ 撥打視像電話





1. 當手機已正確地置於通話座時，傾斜通話座至想要的位置以調較相機和檢視角度。
2. 如您 Nokia 6630 手機的使用指南中所述撥打或接聽視像電話。如要錄製影像，使用通話座的相機。至於聲音方面，您可以使用手機的喇叭和麥克風或已連接至手機的藍芽耳機。


保養及維修

本裝置是通過優良技術設計的產品，務請小心使用。以下建議有助您在適用的保養範圍內提供保障。




- 請將所有增強配套置於兒童無法觸及的地方。
- 請保持裝置乾燥。雨水、濕氣與各種液體或水份可能含有腐蝕電路的礦物質。
- 請勿將裝置存放在佈滿灰塵、髒亂的地方或在該地方內使用裝置。活動式的零件和電子元件可能較容易損壞。
- 請勿將裝置存放在高溫地方。高溫可能會縮短電子裝置的壽命、破壞電池，並使某些塑膠零件變形或融化。
- 請勿把裝置存放在低溫地方。當裝置升溫至其正常的溫度時，其內部可能會產生濕氣，損壞電路板。
- 不要嘗試用本指南提供指引以外的方式開啓裝置。
- 請勿扔擲、敲擊或搖晃裝置。粗暴的使用方式可能會破壞內部的線路板和完好的結構。
- 請勿使用刺激性的化學製品、清潔溶劑或腐蝕性的清潔劑來清潔裝置。
- 請勿為裝置塗上顏料。塗料可能會妨礙裝置的活動式零件，妨礙正常操作。
- 使用柔軟、清潔和乾燥的布清潔鏡頭 (例如：相機、距離感應器和光暗感應器鏡頭)。

如果裝置不能正常操作，請送交最近的授權服務商店獲取服務。






Nokia 視訊電話機座 PT-8 用戶指南 (Nokia 6630 用)



第 1 版



DECLARATION OF CONFORMITY (聲明)

本公司 (NOKIA CORPORATION) 聲明產品 PT-8 符合下列說明委員會 (Council Directive) 的規定：1999/5/EC。

此聲明 (Declaration of Conformity) 的全文可在
http://www.nokia.com/phones/declaration_of_conformity/找到。



Copyright © 2004 Nokia. 版權所有。

未取得 Nokia 的書面同意，嚴禁以任何形式複製、傳送、散佈或儲存全部或部分的內容。

Nokia 與 Nokia Connecting People 及 Pop-Port 是 Nokia Corporation 的註冊商標。本文中提及的其它產品與公司名稱可能分別為其各自擁有者之商標或註冊名稱。

Nokia 奉行持續發展的政策。Nokia 保留對本文件中所描述產品進行變更或改進的權利，恕不另行通知。

在任何情況下，對資料遺失、收益損失或因此所造成任何特別、意外、隨之而來或非直接的損壞，Nokia 恕不負責。

本文件的內容依「現有形式」為準。除非適用的法律另有規定，否則不對本文件之準確性、可靠性或內容做出任何類型的明確或隱含的保證，其中包括但不限於對特定目的的商用性與適用性的默示保證。Nokia 保留於任何時刻修正或作廢此文件的權利，恕不另行通知。

特定產品的取得依地區而有所不同。請跟您最近的諾基亞經銷商聯絡。

第 1 版





目錄




目錄

安全規定	4
簡介	5
1. 概觀	6
2. 使用機座	7
請將手機放置於此機座	7
撥打視訊電話	8
保養與維護	9



中文台灣



安全規定

安全規定

請閱讀下列簡明的使用原則。不遵從這些原則可能會產生危險或觸犯法律。請閱讀整篇用戶指南以取得詳細資訊。



合格的服務
僅有合格的人員可安裝或維修此產品。



連接至其它裝置
當連接至其它裝置時，請閱讀此用戶指南以取得詳細的安全指引。請勿連接不相容的產品。



防水功能
您的裝置無防水功能。所以請保持乾燥。

當使用裝置的功能時，請遵守所有法令及尊重他人的隱私權與法律權利。

■ 充電器與電池

在為裝置充電前，請先檢查充電器型號。此裝置是設計來使用 AC-1 及 ACP-12 充電。



警告！在此特定裝置上請僅使用 Nokia 核可的電池。使用任何其它類型的電源裝置可能不被認可或違反保固條款，並可能導致危險。

有關認可之充電器的可用性，請洽詢您的經銷商。

切斷任何配件的電源時，應拔起插頭而不是拉扯電源線。

簡介

您能在 Nokia 6630 手機上使用 Nokia 視訊電話機座 PT-8 來進行免持聽筒的視訊電話。因為它可折疊、體積微小且重量輕，便於隨身攜帶。

請在使用此機座前先仔細詳讀本用戶指南。更多詳細資訊均在 Nokia 6630 手機的用戶指南中。請勿以本用戶指南取代您手機的用戶指南，因為手機的用戶指南含有許多重要的安全與維護資訊。請注意此機座僅設計用於室內。


您可以以下方法使用此機座：

- 在視訊電話時，您可以從手機螢幕中觀賞自己及其它來電者的影像。
- 微調機座的位置，以調整相機及觀賞角度。
- 當您希望私密通話時，請使用手機的藍芽耳機組，例如 Nokia 無線耳機組 HDW-3。
- 當手機連接至此機座時，請正常使用手機功能。此機座使用手機的喇叭與麥克風。
- 當手機連接至此機座時請充電。

概 觀

1. 概觀

Nokia 視訊電話機座包含以下組件：



相機鏡頭 (1)

指示燈 (2) 當此機座以 AC-1 或 ACP-12 充電器充電，或手機已插入 Pop-Port 連接埠時，此燈號會呈現綠色。當燈持續亮起時，手機與此機座均已待機可進行視訊電話。

Pop-Port 連接埠 (3)

充電器插口 (4)


DC 纜線 (5) 當手機已放置於此機座，且 DC 插頭已連接至手機時，則 DC 纜線可將手機充電。

使用機座

2. 使用機座

■ 請將手機放置於此機座

1. 從機座後方卸除 dc 纜線的一端。



2. 將機座連接至 AC-1 或 ACP-12 充電器。




3. 將充電器的一端連接到牆上的插座。指示燈會呈現綠色閃爍。
使用時請保持機座連接至牆上的插座。

中文台灣

使用機座

4. 請將手機插入機座，並將 DC 纜線的一端插入手機的充電器插口。



充電器也為手機電池充電。

5. 檢查指示燈是否呈綠色亮起，表示機座已待機可用。

■ 撥打視訊電話

1. 當手機已適當放置於機座，請微調機座的位置，以調整相機及觀賞的角度。
2. 依您的 Nokia 6630 手機用戶指南所述，撥打或結束視訊電話。
如需錄製影片，請使用此機座的相機。如需收聽，您可以使用手機麥克風或喇叭，或連接至手機的藍芽耳機組。

保養與維護

本裝置為具有優質設計及技術的產品，應妥善維護。下列建議有助於您履行保固期內的所有責任和義務。

- 把所有週邊裝置放置於兒童不能觸及的地方。
- 請保持本裝置乾燥。雨水、濕氣和各種液體或水分都可能含有礦物質，會腐蝕電子線路。
- 請勿在滿佈灰塵、骯髒的場所使用或存放本裝置。否則其拆卸式組件及電子組件可能會受損。
- 請勿將本裝置存放在高溫處。高溫將縮短電子裝置的壽命、損壞電池、並使某些塑膠零件變形或融化。
- 請勿將本裝置存放在低溫處。本裝置恢復常溫狀態時，內部凝結的濕氣可能會損壞電路板。
- 請勿嘗試未依此指南的指示開啓裝置。
- 請勿扔擲、敲擊或搖晃本裝置。粗暴的使用方式可能會損壞內部電路板及精密機械。
- 請勿使用刺激性的化學製品、清潔溶劑或腐蝕性的清潔劑來清潔本裝置。
- 請勿為本裝置上色。油漆可能阻塞活動式的零件，使用無法正常操作。
- 請使用柔軟乾淨的布來清潔任何鏡片 (例如相機、距離感應器及感光器鏡片)。

如果裝置無法正常運作，請將其送至距離您最近的合格維修處所。

